

Automatic Callback



When you place a call and receive a busy signal, this service commands your telephone to continuously dial the busy number for up to 30 minutes until it gets through. You only have to dial the first time.

- After having received a busy signal, press and release the switchhook. Listen for dial tone and press *66 (or dial 1166 on a rotary phone)
- Your phone will continuously dial the busy number for 30 minutes. (After 30 minutes, you will need to reactivate the service.)
- When the line becomes available, you will be notified by a special ring. As soon as you pick up the receiver, your call will be placed automatically.
- You may use your phone to place and receive calls while this service is activated and you may have this service activated to more than one number at a time.
- If you wish to cancel an Automatic Callback, press *86 (or dial 1186 on a rotary phone).